



*** Brace Bracket**

Box Size

Part Number

B3

BB3x

B9

BB9x

B12

BB12x

B16

BB16x

B24

BB24x

B30

BB30x

B36

BB36x

**Also need Trace antenna spacer for optimum RF installation
 x=I for Itron, B for Badger Orion, D for Datamatics, or T for Trace**

**Vintage Water Works Supply
 110 Dry Creek Rd. Healdsburg, CA 95448
 707-431-7473 FAX-707-431-0431 E-mail Mike@vintagewws.com
 * Patent Pending**